

Instructions Manual

For

Popcorn-Pot

The popcorn-pot is specifically designed for outdoor use over an open fire. The container can hold 4, 4 litres or approximately the product of 3 dl popcorn.

The container is made of regular iron with no heavy metals, and in order to prevent corrosion, the following procedure is recommended:

1. Before the container is initially used, it must be carefully washed using hot water and washing-up liquid.
2. Oil the container using a small amount of cooking oil. Mount the wood-handle using the small screw (enclosed).
3. Place the container over a blazing fire. When the container is well heated, and the oil smokes (burns off), it's ready for use.

After further use of the popcorn-pot, you may clean it as needed using a pot scourer or the like.

You can also burn off the dried-in oil by superheating the empty popcorn-pot over the fire. The "dirt" will burst into flames and can be brushed off after cooling down. Remember to oil the pot afterwards using cooking oil.

The best result is obtained using popcorn and plenty of oil (half the popcorns must be covered in oil). The pot must be kept over a blazing fire or a thick layer of embers. Shake the pot lightly, when the popcorns starts popping briskly.

If you have further questions, please contact your distributor.